

Pro Series Firmware Change Notes



Purpose:

This document contains release notes for the firmware relating to the ProDSS, ProSolo, and ProSwap Handhelds, Probes, and Sensors.

Instrument	Latest Version
Pro Series Handhelds	
ProDSS, ProSwap, ProSolo	1.3.35
Cable/Probe Assemblies	
ODO-T, ODO-CT	3.2.15
ProDSS 4-port	1.0.0
ProSwap 1-port	1.0.9
ProSwap Logger	1.0.24
ProDSS Sensors	
pH, ORP, NH ₄ , Cl, NO ₃	3.0.0
Turbidity	3.0.4
CT, ODO, TAL-PC, TAL-PE	3.0.5
Depth	3.1.8

ProSwap Logger Firmware v1.0.24
March 2025

What's New:

Bug fix to improve sensor connection to ProSwap Logger.

Change Notes:

- Ensures sensors enter sleep mode properly to improve power efficiency and battery life

PREVIOUS UPDATES

ProSwap Logger Firmware v1.0.23 March 2024	<p>What's New: Bug fixes to improve ProSwap Logger interfacing with Blu-X and ISE sensor data reporting.</p> <p>Change Notes:</p> <ul style="list-style-type: none">• Improvements to the ProSwap Logger interface with Blu-X• Fixed an issue that caused ISE mV and mg/L values to be transposed when data was relayed to Kor or a handheld
ProSwap Logger Firmware v1.0.22 January 2024	<p>What's New: Bug fixes for ProSwap Logger communication with Blu-X.</p> <p>Change Notes:</p> <ul style="list-style-type: none">• Fixed an issue that caused sensors to disappear when integrated with Blu-X
Pro Series Firmware v1.3.35 January 2024	<p>What's New: Bug fixes to improve data formatting.</p> <p>Change Notes:</p> <ul style="list-style-type: none">• Fixed an issue that caused improper formatting in data backup when "Include Sensor Info" was unchecked
Pro Series Firmware v1.3.34 August 2022	<p>What's New: Bug fix to improve calibration accuracy.</p> <p>Change Notes:</p> <ul style="list-style-type: none">• Fixed an issue that caused an incorrect ORP value to populate during calibration
Pro Series Firmware v1.3.33 June 2022	<p>What's New: Bug fix to improve calibration accuracy.</p> <p>Change Notes:</p> <ul style="list-style-type: none">• Fixed issue that prevented Cl calibration restore and Cl from appearing in the sensor menu• Added missing pre-calibration values for Kor calibration record parsing• Fixed QC score query for Kor calibration record parsing• Force barometer stability status• Added missing Korean and Thai translations• "Start Logging Now" changed to start logging even if there is a time discrepancy between the handheld and logger• Added cable and battery voltage readings for ProSwap Logger• Fixed gauge pressure display for ProSwap Logger

PREVIOUS UPDATES

Pro Series Firmware v1.3.33 (continued)

June 2022

- Fixed over-scrolling menu display issue on Probe->Display menu for ProDSS and ProSwap without GPS
- Increased maximum view lines from 1,000 to 10,000
- Fixed gauge depth calibration inconsistency
- Fixed wrong temperature being displayed for barometer calibration on ProSwap Logger when C/T sensor was connected
- Fixed issue that prevented the ProSwap Logger battery and voltage information on non-GPS handhelds from showing
- Added ProSwap Logger operating mode to deployment status page
- Fixed an issue that caused the ProSwap Logger to enter real-time mode when plugged in



YSI Incorporated
1725 Brannum Lane
Yellow Springs, OH 45387

Tel +1 937.767.7241
Email info@ysi.com
YSI.com

All information presented herein is believed reliable and in accordance with accepted engineering practices. Xylem makes no warranties as to the completeness of this information. Users are responsible for evaluating individual product suitability for specific applications. Xylem assumes no liability whatsoever for any special, indirect or consequential damages arising from the sale, resale or misuse of its products. Subject to change without notice.

© 2024 Xylem Inc. or its affiliate. All rights reserved.

XA00308-02 0325

xylem
Let's Solve Water